



Tornambe Eye Level

REF TR9049-11



Directions For Use

1. Remove the protective cover from the adhesive back.
2. Place the eye level over the patients eye patch with the air bubble at the 12 o'clock hour.
3. Position patient so that the air bubble is at the clock hour suggested by the surgeon.



Escalon Medical Corp. | 2440 South 179th Street | New Berlin, WI 53146

800-486-4848 | 262-821-9182 | www.sonomedescalon.com

5540 Rev. E (ECO101026)